LAMP


AZ-GD231-HL MULTI-PURPOSE LID (W/DAMPER)

Installation instructions

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

- Damper allows silent closing of lid.
- Side plates for anti-pinch function.



FOR YOUR SAFE WORK AND CORRECT INSTALLATION

Meaning of symbols











/ **!**\ **Caution** If not followed injury or damage may result.

- 1 The AZ-GD231-HL is designed to function when installed vertically as shown below. Horizontal, slanted or upside down installation will result in improper function and may lead to injury.
- 1 To prevent the risk of the product falling and causing injury, ensure that the AZ-GD231-HL is securely fastened to a structure with adequate strength.
- Do not disassemble nor modify any parts other than those described in this document.
- 1 The closing speed of the lid may vary according to ambient temperature .If the product is stored below zero degrees, please store in room temperature for several hours before use.

Parts description


Description	Quantity
Flap lid body	1
Warning sticker	1
Cover cap	4

Tools needed for instalation


- Edge tape
- Screws (not provided)

Choose the suitable length according to the material to be mounted. Recommended screw: 4mm tapping screw · · · · · 6 pcs

Dimension drawing




Cutout dimensions



Installation procedure




Make sure that the LAMP logo is at the top.



2 Stick the edge tape around the hole. Edge tape (not provided)

- (1) Fasten the unit with six screws.
- (2) Make sure that the final assembly is securely fastened.






Slowly open and close the lid completely a few times in order to ensure correct operation.



Cover the holes with the provided cover caps.



6

Paste the warning sticker in a visible position to avoid any injury when using the lid.



SUGATSUNE KOGYO CO., LTD. Tokyo, JAPAN Phone: +81 3 3866 2260 E-mail:export@sugatsune.co.jp

SUGATSUNE KOGYO (UK) LIMITED Reading, UK Phone: +44 1189 272 955 E-mail:sales@sugatsune.co.uk

SUGATSUNE EUROPE GmbH Düsseldorf, GERMANY Phone: +49 211 53812 900 E-mail:sales@sugatsune.eu

SUGATSUNE AMERICA, INC. California, USA

Phone: +1 310 329 6373 E-mail:sales@sugatsune. Chicago, USA Phone: +1 630 317 7072 E-mail:sales@sugatsune.com

SUGATSUNE CANADA, INC. Montreal, CANADA
Phone: +1 514 312 5267
E-mail:support@sugatsune.ca

SUGATSUNE SHANGHAI CO., LTD. Shanghai, CHINA
Phone: +86 21 3632 1858
E-mail:lamp@sugatsune.com.cn Guangzhou, CHINA Phone: +86 20 6639 3554 E-mail:lamp@sugatsune.com.cn

SUGATSUNE KOREA CO., LTD. Incheon, KOREA
Phone: +82 32 220 0003
Phone: +82 32 220 0003

Delhi, INDIA Phone: +91 9867299597 +91 11 45093636 E-mail:sales@sugatsune.i

ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.