LAMP. GH-G07SHK STAINLESS STEEL GRAVITY HINGE FOR **GLASS DOOR INSTALLATION MANUAL**

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

Usable in wet conditions such as shower rooms.

The door closes automatically when the door is open at less than 70°. It opens automatically between about 70° and 160°

The door can be held open by placing a door stopper in this area. When removing the door, the shaft that inserts into the hinge will not fall out.

SPECIFICATIONS

| | per 2 hinges | per 3 hinges |
|---------------------|--------------|--------------|
| Max. Door height | 2100 mm | 2400 mm |
| Max. Door width | 800 mm | 850 mm |
| Glass thickness | 8 — 12 mm | |
| Max. Door weight 涨¹ | 45 kg | 50 kg |

*¹ Prioritize the load capacity when determining the glass size.

FOR YOUR SAFE WORK AND CORRECT INSTALLATION

Meaning of symbols



⚠ Caution: If not followed, injury or damage may result.

It is necessary to manufacture the frame with sufficient strength so that it endures the weight of the door and any impact upon opening/closing the door. Only use designated screws and ensure that they are fastened firmly. A frame with poor strength or loose screws might result in the door falling and causing injury.

- ∞ Do not try to use this product for anything other than its original purpose. Do not use any part for applications outside of its specification.
- Pollow the specified dimensions, specifications, and alignment of the door and frame. Warping, tilting or twisting of the frame or door may cause failure.
- This product is a part for architectural fittings. After installation, please check the function and safety of the final product. Please inform the end user how to use the product safely.
- Use tempered glass. Using shatter-proof film is recommended. For areas where the products grip, it is recommended to remove the shatter-proof film before installing. If left unremoved, slippage due to the shatter proof film may affect the proper function of the door. Please consult with the glass and film suppliers before proceeding.
- () Make sure to check the screws for slack at regular intervals (one month from first usage, half a vear, and then one time every year is recommended).

TOOL REQUIRED

Philips screwdriver ⊕No.2

Allen kev $\bigcirc 2.5$ $\bigcirc 4$


SCREWS Provided screw

Countersunk head screw M5 × 14 ... 3 pcs/hinge (for hinge fixed.) Shaft fixing screw1 pc/hinge (for shaft fixed.) Hexagon socket countersunk head screw M6 × 14 ... 2 pcs/hinge (for glass fixed.)

Sold separately (If screws are lost.) Countersunk head screw $M5 \times 15$ Hexagon socket countersunk head screw M5 × 15



INSTALLATION Left-hand opening shown. The right-handed opening is symmetrical.



Montreal, CANADA Phone: +1 514 312 5267 E-mail:support@sugatsune.ca Phone: +49 211 53812 900 E-mail:sales@sugatsune.eu ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

SUGATSUNE KOREA CO., LTD. Incheon, KOREA Phone: +82 32 220 0603 E-mail:sales@sugatsune-korea.co.ki

2023.03 1523-2