LAMP

INSTALLATION MANUAL HES

FOR HES3D-120-A100 CONCEALED HINGE

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

- This product is a concealed hinge for indoor use to be recessed in the cut out on door and doorframe.
- 3 way adjustment function allows vertical, horizontal, and depth adjustment.

DOOR SPECIFICATION

Min. Door thickness	29 mm
Max. Door weight	30kg per 2 hinges, 40kg per 3 hinges
Max. Door size	Width: 900 mm, Height: 2400 mm

COMPONENT PARTS (PER BOX)

Concealed hinge

· Screw cover

Template

Countersunk head tapping screw 5x20

· Hex Key 3 mm

2 pcs

4 pcs x 2 bags

1 pc

4 pcs x 2 bags

1 pc

FOR YOUR SAFE WORK AND CORRECT INSTALLATION

Meaning of symbols



Caution



Prohibited




Required

Caution: If these cautions are not followed, it may result in injury or damage.

- It is necessary to manufacture the frame with sufficient strength so that it endures the weight of the door and any impact upon opening/closing the door. Only use designated screws and ensure that they are fastened firmly. A frame with poor strength or loose screws might result in the door falling and causing injury.
- Openot try to use this product for anything other than its original purpose. Do not use any part for applications outside of its specification.
- Ouse in conjunction with a door closer is not recommended. For soft-close option, we recommend Sugatsune LDD-V or LDD-S door damper
- Make sure to follow the designated dimensions, specifications, and horizontal/vertical angles. Make sure that the frame is not warped, since it may affect the movement of the door.
- This product is a part for architectural fittings. After installation, make sure to test the finished product thoroughly to ensure that it is well-functioning and safe. Please inform the end user about general precautions and safety to prevent improper use.
- Make sure to check the screws for slack at regular intervals (one month from first usage, half a year, and then one time every year is recommended).
- ❶ Be sure to use a door stopper which restrict the opening angle within 100°. If not, the hinge may be broken and the door may fall.

INSTALLATION DRAWING (EXAMPLE)


CUT OUT DRAWING FOR DOOR AND DOORFRAME




Installing Base frame to Cabinet

2 Installing Hinge to Door

3 Hanging Door






- [1] Insert each hinge body (door side) deep into the base frame
- [2] Hang the hinge body on the base frame.(Provisional holding state)

Caution

- Do not move the door at this stage as it may fall off.
- [3] While supporting the door, quickly tighten and secure the up and down adjustment screws to the position shown on the left.

ADJUSTING DOOR POSITION

*Adjustment direction indicates the direction with the door closed.



Vertical adjustment

- Loosen the adjusting screw one turn.
- 2Lifted the door to the correct height.
- 3Finally, secure the adjusting screw.

Horizontal adjustment

4 Rotate the adjustment screw to the correct position.

Depth adjustment


6Loosen the adjusting screw one turn and secure it in the optimum position.

Caution ·


come off.

O Do not remove the depth adjustment screw. The door may fall and cause injury. When adjusting the horizontal position, turn the two screws a little, by the same amount. The hinge may be broken if you keep turning one screw only. If you turn the adjustment screw to the right beyond the adjustment range, the parts will protrude, and the cover won't fit, and if you turn it further, the door will

INSTALLING DOOR STOPPER



Attaching the Screw Cover



SUGATSUNE KOGYO CO., LTD. Tokyo, JAPAN Phone: +81 3 3866 2260 E-mail:export@sugatsune.co.jp

SUGATSUNE KOGYO (UK) LIMITED Reading, UK Phone: +44 1189 272 955

E-mail:sales@sugatsune.co.uk

SUGATSUNE EUROPE GmbH Düsseldorf, GERMANY Phone: +49 211 53812 900 E-mail:sales@sugatsune.eu

SUGATSUNE AMERICA, INC. California, USA Phone: +1 310 329 6373 E-mail:sales@sugatsune.com

Chicago, USA Phone: +1 630 317 7072 E-mail:sales@sugatsune.com

SUGATSUNE CANADA, INC. Montreal, CANADA Phone: +1 514 312 5267

E-mail:support@sugatsune.ca

SUGATSUNE SHANGHAI CO., LTD. Shanghai, CHINA Phone: +86 21 3632 1858 E-mail:lamp@sugatsune.com.cn

Guangzhou, CHINA Phone: +86 20 6639 3554 E-mail:lamp@sugatsune.com.cn

SUGATSUNE KOREA CO., LTD. Incheon, KOREA

Phone: +82 32 220 0603

SUGATSUNE KOGYO INDIA PRIVATE LIMITED Mumbai, INDIA Phone: +91 9867299597 E-mail:sales@sugatsune.in

Delhi, INDIAPhone: +91 9867299597
+91 11 45093636 E-mail:sales@sugatsune.in